



why! W670SZQ1 Replacing extension RAM

Write a short summary.



Written By: Felice Suglia



INTRODUCTION




Describe what you will do.

Step 1 — Battery




- Unlock the left latch.
- Unlock the right latch.
- Remove the battery while maintaining the unlocked latch.

Step 2 — Access to the Main Components



- Using the Philips screwdriver # 0, remove the 2 screws from the bottom cover.
- Lift the bottom right cover with the iFixit Opening Tool.
- Lift the cover lower left with the iFixit Opening Tool.
- Finally completely clear the lower cover to view the main components.

Step 3 — RAM Memory



- Locate the RAM module into the slot.
- Spread the leaf springs that hold the memory module in place (left and right).
- Remove the memory module (RAM) of its connector.

Pour réassembler votre appareil, suivez les instructions dans l'ordre inverse.

This document was last generated on 2017-07-06 07:55:49 PM.